PRODUCT MANUAL

Homemory 24-Pack Flameless LED Tea Light Candles

Seven-color changing light
White plastic body • Battery powered • Manual on/off switch

Model listed in product information: BKTL2032

This guide summarizes the product details currently available for this model. It is a store-prepared guide, not a manufacturer-issued manual. If markings on the product or the manufacturer's instructions differ, follow the manufacturer's instructions.

1. What's Included

• 24 white-body flameless LED tea lights
• One pre-installed CR2032 coin-cell battery in each light, according to the supplied product information
• No remote control or automatic timer is specified

2. Product Specifications

Feature	Details
Quantity	24 tea lights
Light effect	LEDs cycle through seven colors; a fixed-color setting is not specified
Body color / material	White body; polypropylene / plastic
Dimensions (each)	Approx. 1.5 in (diameter) × 1.3 in (height)
Battery	CR2032 coin cell; pre-installed and replaceable; listed as 240 mAh
Voltage / listed power	3 V / 0.72 W (as supplied in product information)
Stated runtime	200+ hours; actual runtime may vary with use and battery condition
Controls	Manual on/off switch on each light; no remote or timer
Water resistance	Not waterproof; do not submerge
Model number	BKTL2032 (listed model number; not independently confirmed as an MPN)

3. Setup and Operation

Before first use

1. Unpack the lights and inspect each body and battery cover for damage.
2. Confirm that each light fits the intended holder. The listed dimensions are approximately 1.5 inches across and 1.3 inches high.
3. Test each light in a dry, stable location before arranging the display.

Turning the lights on and off

Use the manual switch at the base of each tea light. Switch each light off individually after use. This model does not specify a remote control or automatic timer.

Color-changing effect

The LED cycles through seven colors. The supplied product information does not specify a way to select or lock a single color.

4. Battery Care and Replacement

Each light is described as having a pre-installed, replaceable CR2032 coin-cell battery. If a light stops working or becomes dim, switch it off and consult the battery-compartment markings before opening it. Replace the cell only with a compatible CR2032 battery, observing the polarity shown in the compartment. Close the battery cover securely before using the light again. Do not force the cover or use a light with a damaged battery compartment.

Coin-cell batteries can cause severe injury if swallowed. Keep new and used batteries away from children. Seek urgent medical assistance if a battery may have been swallowed or placed inside the body. Dispose of used batteries in accordance with local regulations; do not place them in household fire.

5. Care and Safety

- **Keep dry:** These lights are not waterproof. Do not use them in water, submerge them, or expose the battery compartment to moisture.
- **Inspect regularly:** Stop using a light if its body, switch, or battery compartment is cracked or damaged.
- **Use a stable surface:** Place lights where they will not easily fall, and keep switches accessible.
- **Keep away from small children:** Small parts and coin-cell batteries present a swallowing hazard.
- **Decorative use:** These are flameless lights, but they are still battery-powered electronic products. Do not modify them.

6. Troubleshooting

Issue	What to check
Light does not turn on	Check the base switch. If it still does not work, inspect the battery compartment and battery orienta
Light is dim or stops working	The battery may need replacement. Use a compatible CR2032 cell and close the compartment se
Color does not change immediately	Allow time for the LED cycle to progress. The product cycles through colors; a fixed-color selection
Light has become wet	Stop using it. Do not submerge it or operate it if moisture may have entered the housing or battery

7. Important Notes

The 200+ hour runtime is a stated product claim, not a guaranteed operating time. Actual performance can vary. No remote control, timer, waterproof rating, or fixed-color selection is specified in the product information used to prepare this guide. Package contents and specifications should be checked against the items received.