SEASONAL LIGHTING / PRODUCT GUIDE

Fall Garland with Lights

Setup, operation, placement and care

Brand listed: Wabarle | Model: Fall Garland -8

PRODUCT AT A GLANCE

A warm accent for autumn displays

This battery-powered foliage garland is designed for fall, Halloween and Thanksgiving decorating. Its orange illumination can complement mantels, shelves, table displays and other suitable seasonal arrangements.

50 orange LED bulbs	8 modes lighting effects	3 x AA batteries required	Timer cycle not specified

Package contents

The supplier listing states that the package includes:

- 1 lighted fall garland
- 1 instruction sheet

Important information before use

Specifications to confirm: Supplied listing details conflict on the garland length (9.8 ft, 120 in, and 15 ft are all shown) and leaf material (plastic in item details, fabric in marketing text). Check the actual item or package if these details matter. No IP rating or timer cycle duration was supplied.

This is a customer product guide prepared from available listing details. It is not an official manufacturer-issued manual. Where the included instruction sheet differs, follow the manufacturer instructions.

SETUP & OPERATION

Prepare the garland for use

Set up the garland before arranging it in its final position. Check the wiring, bulbs and battery compartment first. Do not use the product if you find visible damage.

01 Inspect the package
Remove the garland and instruction sheet. Look for visible damage to the wires, bulbs, controller and battery compartment.

02 Install the batteries
Use 3 AA batteries (not included). Match the positive and negative marks in the battery compartment. Close the compartment securely.

03 Test the lights
Operate the push-button control before hanging the garland. Confirm that the lights turn on and respond to the control.

04 Choose a suitable location
Place the garland on a stable, suitable support. Keep the control box accessible and avoid placing wires where they may snag or create a trip hazard.

Lighting modes

The product listing states that eight lighting modes are available. It names examples, but does not provide the complete mode sequence. Use the push-button control and the supplied instruction sheet to identify each mode.

Mode information supplied by the listing	What to do
Steady-on	Consult the included instruction sheet for the exact button sequence.
Slow fade	Use the controller to select the effect if available on your unit.
Flashing	Check the supplied instructions for the mode order.
Sequential effect	The exact sequence is not specified in the available details.

Using the built-in timer

A timer is listed, but the available product details do not specify its on/off schedule, duration, or programming steps. Refer to the instruction sheet provided with the product. Do not rely on a timer cycle taken from a similar garland.

Battery reminder: Replace batteries only with the correct type. Do not mix old and new batteries, or different battery types. Insert them using the polarity marks. If a battery leaks, avoid contact with the liquid and clean the compartment safely before reuse.

PLACEMENT, CARE & TROUBLESHOOTING

Enjoy your seasonal display safely

The garland is listed for indoor and outdoor use and described as water-resistant. However, no IP rating was supplied. Treat outdoor placement cautiously and protect the controller and battery compartment from moisture.

Suggested decorating locations

- Mantel or shelf: Keep the garland away from open flames, candles and hot surfaces.
- Table display: Keep the lights away from food, hot cookware and busy serving areas.
- Window or banister: Do not block handles, stairs, exits or access routes.
- Protected porch: Use only where the product can be kept within the manufacturer's stated conditions. Do not immerse or spray the battery compartment.

Care and storage

- Switch the lights off before repositioning or inspecting the garland.
- Keep the product away from excessive heat, sharp edges and open flames.
- Avoid pulling on the wiring or forcing sharp bends around tight corners.
- Keep the control box accessible and dry. Do not immerse the product in water.
- When storing the garland, keep it in a dry location where the wires will not be crushed or sharply kinked. Consider removing the batteries for long-term storage.

Troubleshooting

Problem	Checks to try
Lights do not turn on	Check that 3 AA batteries are installed with the correct polarity. Check that the compartment is closed and the batteries are not depleted.
Mode does not change	Press the control again and consult the included instruction sheet for the mode sequence.
Timer behavior is unclear	The available listing does not give the timer schedule. Use the instructions supplied with the item.
Garland will not stay in place	Gently reshape the foliage and check the support. Do not pull the wires or force tight bends.

Stop use if damaged

Stop using the garland if wires, bulbs, controller or battery compartment are damaged, unusually hot, or show signs of corrosion. Do not attempt electrical repairs. Keep batteries and small parts away from children and pets.

Reference details
Brand listed: Wabarle | Model/MPN listed: Fall Garland -8
Light source: LED | Light color: Orange | Quantity: 1 garland
Battery requirement: 3 AA batteries (not included)

This guide is based on the available product listing details. Confirm exact length, leaf material, timer operation, and permitted outdoor conditions with the product packaging or manufacturer instructions.