


Homemory Flameless LED Candles for Halloween

24-piece set • Setup, placement, care and safety



Important: This is an independent LightDecorHub customer guide, not an official Homemory manufacturer manual. Use the product packaging and manufacturer instructions as the final authority for operation and safety.

What this guide covers

- Identifying the set and checking what arrived
- Choosing a suitable display location
- Safe handling, cleaning and storage
- Basic checks if a candle does not light
- Product facts that still need confirmation from the packaging

Product identity used for this guide: Homemory flameless LED decorative candles for Halloween, listed as a 24-piece set.

1. Check the Set Before Use

Open the package carefully and compare the contents with the packing information supplied with your order. This listing is described as a 24-piece set. Confirm the quantity and condition before arranging the candles.

- Check each candle for cracks, loose parts, corrosion or other visible damage.
- Keep the packaging and any instruction sheet so you can check the exact model and operating requirements.
- Look for the manufacturer's details about batteries, switches, charging (if applicable), controls and included accessories.
- Do not assume a remote, timer, batteries or spare parts are included unless the package says so.

2. Setup and First Use

The exact battery type, battery compartment design, switch location and operating steps have not been confirmed for this specific product. Follow the instructions provided with your set rather than using directions for a similar-looking candle.

- Place the candle on a stable, level surface before operating it.
- Install or replace batteries only if the product instructions specify the correct type and orientation.
- Do not mix old and new batteries, or different battery types, if the unit uses replaceable batteries.
- Close any battery compartment securely before use and keep small batteries away from children and pets.
- If the unit uses a control, remote or timer, verify that accessory is included and follow its supplied instructions.

3. Display and Placement

Use the candles to style Halloween tables, mantels, shelves or seasonal arrangements. Leave enough space around each unit to prevent falls, crushing or accidental contact with decorations.

- Keep candles away from heaters, open flames and other sources of excessive heat.
- Avoid locations where people may trip over, knock over or crush the candles.
- Keep the set away from children and pets unless an adult is supervising.
- Do not place candles where water can enter battery compartments or electrical components.

Outdoor-use caution: The supplier listing title uses the word “waterproof,” but the exact IP rating and permitted exposure conditions are unverified. Do not expose the candles to rain or standing water unless the manufacturer’s instructions explicitly permit that use.

4. Cleaning and Storage

- Turn the unit off before cleaning, if the model has an off switch.
- Wipe the exterior gently with a soft, dry cloth unless the manufacturer specifies another method.
- Do not immerse the candle or spray liquid into openings, switches or battery compartments.
- Remove replaceable batteries for long-term storage only if the product instructions recommend it.
- Store the candles in a dry, cool place away from direct heat and heavy objects.

5. Basic Troubleshooting

Problem	Safe checks
Candle does not light	Check the switch and follow the product instructions for battery type, orientation and installation. Do not force the compartment.
Light appears weak or inconsistent	If the model uses replaceable batteries, check them according to the instructions. Inspect for visible damage.
Housing or compartment is damaged	Stop using the affected unit. Keep it away from moisture and children, and contact the seller or manufacturer for advice.
Water may have entered the unit	Switch it off if safe to do so. Do not operate it until the manufacturer confirms it is safe.

6. Frequently Asked Questions

How many candles are in the set?

The product is listed as a 24-piece set. Check the delivered package against its packing list.

Are the candles definitely suitable for outdoor use?

The supplier listing title describes them as waterproof, but the exact rating and conditions are not confirmed. Check the manufacturer's label or instructions before outdoor exposure.

Are batteries, a remote or a timer included?

Those details are not verified for this exact product. Check the package contents and supplier listing before use.

What are the exact dimensions and runtime?

The dimensions, battery specification and runtime have not been verified for this product. Do not rely on specifications for other Homemory candle models.

7. Verified Product Information

Item	Current information
Brand	Homemory
Product type	Flameless LED decorative candles
Occasion	Halloween / seasonal décor
Pack quantity	24 pieces, based on the current product listing record

Item	Current information
Water resistance	Supplier title says "waterproof"; IP rating and use conditions not verified
Not confirmed	Exact battery type, remote/timer, dimensions, runtime, model number and included accessories

Questions about an order or this guide? Contact info@lightdecorhub.com. For model-specific instructions, use the manufacturer documentation supplied with the product.